
				- 1
ITEM#	QTY	PART#	PART TITLE	
-1	1	RBW5605G00551-3G-1	SHOE	1
-2	1	RBW5605G00551-3G-2	SHANK	1
3	1	CARR-LANE#CL-652-PGH OR FOLITY	PLASTIC PALM CRIP HANDLE 3/8" 16 THREAD Y 5/8" THREAD DR Y 3 3/4" LC	7

PLASTIC PALM GRIP HANDLE 3/8"-16 THREAD X 5/8" THREAD DP. X 3-3/4" LG.





DRAWI	DAKI AEKOSPACE		LID		
DESIG	N VM DART AFROSPACE		ITD		
REV.	DESCRIPTION		ECN#	BY	
D	SEE PREVIOUS REVISION FOR MORE INFORMATION REMOVED ITEMS -3 AND 4 ADDED ITEMS -2 AND 3 -1 REMOVED \$\phi_0.170+0.000/-0.001, 0.188, \$\phi_0.1250-0.1242, 0.375, AND R0.008 MAX DIMS. ADDED 1/4-20 UNC AND 0.38 DIMS		19-911	KPT	

DESIGN DRAWN	VM KPT	DART AEROSPACE LTD HAWKESBURY, ONTARIO, CANADA			
CHECKED MFG. APPR.	MW JFC	TOOL PART # RBW5605G00551-3G		REV. D	
APPROVED	W	TITLE FILLER INSTALLATION TOOL	SCALE NTS	•	
DATE 2019-09-13		COPYRIGHT © 2019 BY DART AEROSPACE LTD THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT			

В

Α

D

NOTES: 1) MATERIAL: N/A

2) HEAT TREAT: N/A

3) FINISH: N/A

4) TOLERANCES: X.X = +/- 0.1" / +/- 1°

X.XX = +/-0.01" / +/-0.5°

X.XXX = +/- 0.005" / +/- 0.1° X.XXXX = +/- 0.0005" / +/- 0.05°

PARALLELISM, ECCENTRICITY AND SYMMETRY ABOUT ALL CENTER LINES = +/-0.005"

5) UNITS: INCHES UNLESS OTHERWISE NOTED 6) IDENTIFICATION: N/A

7) ASSEMBLE AS SHOWN

8) APPLY RED THREADLOCKER LOCTITE 263/262 ON THREADS OF ITEM -2 THEN ASSEMBLE WITH ITEM -1, AND REMOVE EXCESS 9) APPLY RED THREADLOCKER LOCTITE 263/262 ON THREADS OF ITEM -1 THEN ASSEMBLE WITH ITEM -2, AND REMOVE EXCESS 10) THE TOOL ASSY MUST BE PACKAGED WITH A DESICCANT BAG INTO A TIGHT FITTING SEALED PLASTIC BAG

3

